

DESCRIZIONE

Installazione dell'inverter e selezione del Software interno

Questo foglio istruzioni è parte integrante del libretto dell'unità sulla quale viene installato l'accessorio.
A tale documento si rimanda per le AVVERTENZE GENERALI.
L'installazione deve essere effettuata da personale qualificato.

INSTALLAZIONE

- 1 Installare l'inverter procedendo in modo inverso rispetto alla rimozione.
- 2 Selezionare il SW tra quelli riportati di seguito in base alla taglia del fancoil di partenza (vedi etichetta matricolare) e/o alle nuove esigenze tecniche (previa consultazione con il costruttore).

DESCRIPTION

Installation of the inverter and selection of the internal software

Hereby instruction sheet is an integral part of the unit's manual on which the accessory is installed.
Please refer to hereby manual for GENERAL RECOMMENDATIONS.
The installation must be performed by qualified personnel.

INSTALLATION

- 1 Install the inverter performing the same operations as for removal but in reverse.
- 2 Select the SW among those listed below, based on the size of the initial fancoil (see matricular label) and/or new technical requirements (after checked with the manufacturer).



Posizione DIPSWITCH su INVERTER per unità

DIP SWITCH position on INVERTER per unit

1			<p>Cod. INV020003 (Taglia/Size 1...4..) (Std.)</p>
2			<p>Cod. INV020003_1 (Taglia/Size 5...10..) (Std.)</p>
3			<p>Cod. INV020003_2 (Taglia/Size 5..P...8..P)(Pot.1)</p>
4			<p>(Taglia/Size 5..P...8..P)(Pot.2)</p>